SANTÉ

Bruksanvisning

RELIEF Plus
Fotmassage



SANTÉ

Santé Sweden AB
Telefon: +46 20 27 27 20
www.massageprodukter.se

Vi gratulerar till ditt köp av Fotmassage RELIEF Plus.

Genom ditt val av denna massageprodukt från Santé har du tagit ett medvetet steg mot bättre hälsa, ökat välbefinnande och en mer balanserad vardag. Vi är stolta över att få vara en del av din resa mot ökad hälsa, återhämtning och livskvalitet.

Santé strävar efter att erbjuda innovativa och högkvalitativa produkter inom hälsa och välmående. Med fokus på modern teknik, genomtänkt design och användarvänlighet utvecklar vi lösningar som hjälper dig att ta hand om både kropp och sinne – oavsett om det gäller avslappning efter en lång dag eller regelbunden egenvård.

Våra produkter är framtagna med omsorg och noggrant utvalda komponenter för att säkerställa både funktion, hållbarhet och komfort. Vi arbetar kontinuerligt med att förbättra och vidareutveckla vårt sortiment för att möta våra kunders behov och förväntningar.

För att du ska få ut maximalt av din produkt och kunna njuta av dess fördelar under lång tid rekommenderar vi att du läser igenom och följer bruksanvisningen noggrant. På så sätt säkerställer du både optimal användning och en trygg upplevelse.

Tack för att du har valt Santé – vi önskar dig många avkopplande och välgörande stunder!

INNEHÅLL

Säkerhetsanvisningar ----------/sida 1-2

Beskrivning ----------/sida 3

Massagelägen ----------/sida 4

Strömfunktion----------/sida5

Rengöring och underhåll----------/sida 5

Felsökning----------/sida 6



Tack för att du har valt och använder våra produkter.



Läs igenom hela bruksanvisningen före installation och användning.

Säkerhetsanvisningar

- Läs alltid igenom manualen före användning för att säkerställa säker och korrekt hantering.
- Rengöring och underhåll får inte utföras av barn utan tillsyn.
- Produkten kan användas av barn från 8 år samt personer med nedsatt fysisk, sensorisk eller mental förmåga, förutsatt att de får instruktioner eller övervakning och förstår riskerna.
- Barn ska övervakas så att produkten inte används som leksak.
- Produkten har en värmefunktion. Var försiktig om du har känslighet för värme eller nedsatt känsel.
- Om strömkabeln är skadad ska den bytas ut av auktoriserad servicepersonal.
- Försök inte reparera produkten själv.
- Håll produkten borta från vassa föremål och värmekällor.
- Använd inte produkten om klädseln är skadad.
- Koppla alltid ur produkten efter användning.
- Koppla ur produkten före rengöring och underhåll.
- Täck inte över produkten under användning då risk för överhettning och skador kan uppstå.

- Avbryt användningen omedelbart vid obehag.
- Använd inte produkten om den är skadad eller fungerar felaktigt. Kontakta service.
- Använd endast originaltillbehör från tillverkaren.
- Använd inte produkten med våta händer.
- Skydda kontrollpanelen från vatten och vätskor.
- Använd inte produkten i fuktiga eller dammiga miljöer.
- Använd inte produkten i temperaturer över +40 °C.
- Endast för inomhusbruk. Rådgör med läkare före användning om:
- Du genomgår medicinsk behandling
- Du har högt blodtryck, hjärt- eller kärlsjukdom
- Du har tumörsjukdom eller benskörhet
- Du är gravid
- Du använder pacemaker eller annan medicinsk utrustning
- Använd inte produkten när du sover.
- Använd inte produkten om du känner dig sjuk eller påverkad.
- Använd inte längre än 20 minuter per tillfälle.



Varning

Om instruktionerna inte följs kan det leda till allvarliga personskador eller skador på egendom.

Beskrivning



När enheten startas går den i standby-läge och displayen blinkar.

Strömknapp:
Håll in strömknappen för att starta enheten.
Standardläge är:
- Program 1 (P1)
- Intensitet nivå 1
- Lufttryck nivå 1
- Timer: 20 minuter

Håll in strömknappen igen för att stänga av enheten.

MODE KEY:
När enheten startar är den i läge 1 (P1).
- Tryck en gång för att växla till läge 2 (P2)
- Tryck igen för läge 3 (P3)
- Tryck ytterligare en gång för att återgå till läge 1 (P1)

Efter byte av läge blinkar displayen i cirka 2 sekunder innan den återgår till visning av återstående tid.
Program 1 (P1)
Fokuserar på knådande massage av fotsulorna i kombination med lufttryck över fotens ovansida och häl. Ger en kombinerad massage med både luftkompression och mekanisk knådning.

Massagelägen

Läge 2 (P2)

Fokuserar på luftkompression över fotens ovansida och häl samt massage av fotsulor.Lufttrycket är huvudfunktionen, medan rullmassage fungerar som komplement.

Läge 3 (P3)

Fokuserar på kontinuerlig massage av fotsulan samtidigt som luftkompression hålls aktiv över fotens ovansida och häl. Här är rullmassagen huvudfunktion och lufttrycket ett komplement.

Intensitet (rullmassage):
Justera styrkan via intensitetsknappen.
Display visar:
- b0 = av
- b1 = låg
- b2 = hög

Vid b0 är rullmassagen avstängd.

Lufttryck:
Justera luftkompressionen via luftknappen.
Display visar:
- L0 = av
- L1–L3 = stigande intensitet

Värmefunktion:
Tryck på värmeknappen för att slå på eller av värmen.
Indikatorn visar när funktionen är aktiv.


Use hint

Strömfunktion

När enheten startas blinkar displayen. Tryck en gång på strömknappen för att aktivera standardläget. Standardtiden för alla program är 20 minuter.

Efter användning – stäng av produkten och koppla ur den från strömkällan.

OBS:

Produkten är utrustad med överhettningsskydd. Om temperaturen blir för hög stängs enheten av automatiskt. Om detta sker; stäng av produkten, koppla ur den och låt den vila i cirka 15 minuter innan den används igen.

Rengöring och underhåll

Förvaring

Förvara produkten i originalförpackning på en torr och sval plats när den inte används. Undvik att böja eller belasta kabeln. Skydda produkten från vassa föremål, direkt solljus och höga temperaturer. Vid längre tids förvaring – använd ett skydd för att förhindra damm.

Rengöring

Kontrollera att produkten är avstängd och urkopplad före rengöring.

Rengör ytan med en torr trasa. Använd inte frätande rengöringsmedel.

Klädseln kan tas av och handtvättas separat.



Miljöinformation
Produkten får inte slängas tillsammans med hushållsavfall.
Lämna den till återvinning enligt lokala regler och riktlinjer.

Felsökning

Om problem uppstår vid användning, följ stegen nedan. Kontakta service om problemet kvarstår.

Problem	Möjlig orsak	Åtgärd
Ingen massagefunktion	Ingen ström	Kontrollera att produkten är ansluten till strömkälla
Stannar plötsligt	Strömmen är av	Kontrollera strömanslutningen
	Maximal användningstid (20 min) har uppnåtts	Starta om genom att trycka på strömknappen
	Överhettning	Koppla ur och låt produkten svalna i minst 20 minuter
	Blockerade massagehuvuden	Kontrollera att inget fastnat och att fötterna är avslappnade

Tekniska data

Produkttyp: Fotmassageapparat
Produktnamn: RELIEF Plus
Artikelnummer: MP-F58-N-1
Märkspänning: 12 V ⎓
Strömstyrka: 3 A
Effekt: 36 W
Användningstid: 20 min
Vikt: 3,7 kg.
Mått: 445 × 375× 420 mm.

Santé Sweden AB
Org. nr. 556646–7154
Telefon: +46 20 27 27 20
www.massageprodukter.se

EU-försäkran om överensstämmelse

Överensstämmer med europeiska regelstandarder EMC 2014/30/EU och LVD 2014/35/EU.

Garantivillkor:

Återförsäljaren hanterar den lagstadgade garantiperiod för den produkt som beskrivs i denna manual. Garantin gäller från inköpsdatumet. Inköpsdatumet ska styrkas med försäljningskvittot. Återförsäljaren ska kostnadsfritt reparera eller byta ut defekta produkter under garantiperioden. Vanligt slitage täcks inte av garantin. För att nyttja garantirätten returnerar du den defekta produkten innan garantiperiodens slut. Garantin gäller inte om det anses att skadan på produkten uppkommit genom yttre påverkan, eller som ett resultat av reparation eller förändring som inte utförts av tillverkaren eller den auktoriserade återförsäljaren. Garantin från återförsäljaren är begränsad till reparation eller utbyte av produkten. Enligt denna garanti har tillverkaren eller säljaren inget ytterligare ansvar och ansvarar inte för skador orsakade av åsidosättning av bruksanvisningen och / eller felaktig användning av produkten. Om säljarens undersökning av produkten avslöjar att garantikravet relaterar till en defekt som inte täcks av garantin, eller att garantiperioden har löpt ut, ska kostnaderna för undersökning och reparation tillfalla kunden.

Följande orsaker täcks inte av garantin:

- Slitagedelar som tygöverdrag, överdrag eller kåpa.
- Slitage orsakat av felaktig användning.
- Kommersiell användning t.ex. användning på mässor/utställning, upprepad användning utan mellanliggande pauser på 40 minuter.
- Utsättning av enheten för värme, fuktighet eller vätskor.
- Skador på grund av vassa föremål.
- Oönskad förstörelse, överbelastning eller oavsiktlig skada.
- Skador och nedsmutsning av husdjur.
- Kontaminering orsakad av kropps- eller hårvårdsprodukter.
- Skador orsakade av användning av syror, lösningsmedel eller alkohol.

Juridiska anmärkningar: Innehållet i denna manual gör inga påståenden om helande eller läkande effekter. Diagnos och behandling av sjukdomar och andra fysiska åkommor kräver behandling av en läkare, icke-medicinska utövare eller terapeut. Alla uttalanden är strikt informativa och får inte användas som ett substitut för en professionell medicinsk behandling. Varje användare är förpliktigad att genom noggrann undersökning och, om så krävs, samråda med en specialist avgöra om produkten är rätt för deras specifika fall. Varje användning sker på användarens egna risk. Vi tar avstånd från alla läkande påståenden eller löften.

Upphovsrättsskyddade bilder och text omfattas av Santé Sweden AB:s upphovsrätt och får inte användas utan uttrycklig bekräftelse. Copyright © 2026 Santé Sweden AB. Alla rättigheter förbehålls.

Notes

SANTÉ

Instruction manual

RELIEF Plus
Foot massager



Congratulations on your purchase of Foot massager RELIEF Plus.

By choosing this massage product from Santé, you have taken a conscious step toward better health, enhanced well-being, and a more balanced everyday life. We are proud to be part of your journey toward recovery and improved quality of life.

Santé is committed to providing innovative and high-quality products in the field of health and wellness. With a focus on modern technology, thoughtful design, and user-friendliness, we develop solutions that help you care for both body and mind—whether for relaxation after a long day or as part of your regular self-care routine.

Our products are developed with care and carefully selected components to ensure functionality, durability, and comfort. We continuously strive to improve and further develop our range to meet our customers' needs and expectations.

To ensure you get the most out of your product and can enjoy its benefits for a long time, we recommend that you read and follow the user manual carefully. This will help ensure optimal use and a safe experience.

Thank you for choosing Santé — we wish you many relaxing and rejuvenating moments!

CONTENTS

Safety precautions ----------/page 1-2

Description----------/page 3

Operation model----------/page 4

Power switch ----------/page 5

Cleaning and maintenance ----------/page 5

Troubleshooting----------/page 6



Thank you for purchasing and using our products



Read through the entire manual before installation and use!

Saftety precautions

- In order to ensure safe & proper use of the product, please refer to the manual before use.
- Cleaning and user maintenance shall not be made by children without supervision.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children being supervised not to play with the appliance.
  The appliance has a heated surface. Persons insensitive to heat must be careful when using the appliance.
- If the power cord is damaged it must be replaced by the manufacturer or other similarly qualified person.
- Do not try to repair the cord or any other parts by yourself.
- Keep this product away from sharp objects and heat sources.
- If the cloth cover is broken, stop using the product.
- After use, always pull out the power plug from the socket.
- Before cleaning and maintenance, always pull out the power plug from the socket.
- Do not cover the unit while it is on. This can cause failure, damage or over heating on the motor unit.

- If you feel any discomfort during use, immediately stop using the product.
- If the product malfunctions or is damaged, please do not operate. Contact the manufacturer for inspection and reparation
- Do not use accessories not provided by the manufacturer.
- Do not operate the product with wet hands.
- Do not let water or other liquids touch the controls.
- Do not use the unit in a very humid or dusty environment.
- Do not use the unit in places where the temperature exceeds +40°C.
- For indoor use only.
- Always consult your doctor before use if:
  - You are under treatment
  - You have high blood pressure, heart disease, cerebral arteriosclerosis, cerebral thrombosis, malignant tumor, bone osteoporosis.
  - You are pregnant.
  - You are using a pacemaker or other implanted medical apparatus.
- Do not use this appliance while you are asleep.
- Do not use if you are not feeling well.
- Do not use for longer than 20 minutes at a time.



WARNING!
If these instructions are not followed, an accident may lead to serious personal injury or property damage.

Description



Power on, the product into standby mode, display 88 flashing display.

POWER KEY:
Long press the power button, the product starts, the default open mode 1, strength 1 block, pressure 1 block, digital tube shows a 20-minute count-down.
long press the power button again to shut down.

MODE KEY:

After starting the massager in default mode 1 (P1)
press the mode button once to enter Mode 2 (P2).The digital tube display P2.
Press again to enter Mode 3,the digital tube will display P3.
Press again to return to Mode 1,the digital tube will display P1.
After switching the mode, the digital tube will flash for 2 seconds and return to the remaining time display.

Mode 1: Digital tube display P1.The device will focus on giving you the kneading massage on the soles of your feet and air compresion for your instep & heel.Totally you will enjoy pleasure from air compression & mechanical kneading together.

Operation mode

Mode 2: Digital tube display P2.The device will focus on giving you air compression on the instep & heel.Also with intermittently massage on the soles of your feet. Under this mode,air compression are the main focus while soles massage as an auxiliary role.

Mode 3: Digital tube display P3.The device will give the massage on the soles of your feet while air compression(in a state of no air deflating) on your instep & heel be kept for a long time.Under this mode,mechanical massage on soles of feet are the main focus while air compression as an auxiliary role.

INTENSITY KEY:
Press THE STRENGTH KEY TO SWITCH THE MASSAGE INTENSITY OF THE FOOT roller. The digital tube displays b0/b1/b2. When b0 is displayed, the foot roller massage will be closed.

AIR KEY:
Press the pressure to switch the pressure massage intensity. The digital tube displays L0/L1/L2/L3. When L0 is displayed, the pressure massage is closed.

HEATING KEY:
Press the hot button to turn on or off the heating function, and the light will be on or off.


Use hint

Power switch

If the foot massager is powered on, the digital tube flashes. Press the power button once to enable the default mode. The default massage time for all modes is 20 minutes.

When you are finished with the foot massager, please turn off the power and disconnect the plug from the socket.

NOTE! This foot massager is equipped with an overheating protection. If the temperature exceeds the safety temperature, it will automatically stop working. If this happens, shut off the power and disconnect the plug from the socket. Allow the appliance to rest 15 minutes before using again.

Cleaning and maintenance

Storage

When not in use, put the Foot Massager Shiatsu Premium in its box and store it in a dry, cool place. Make sure not to tweak the cord. Avoid sharp objecst so that the surface is not scraped or broken. Do not store in direct sunlight or in a high temperature. If you will not be using the product for a long time, use a dust cover to prevent dust from getting in to the massager.

Cleaning

Before cleaning, make sure that the power is off and that the plug is not connected.

Use a dry cloth to clean the surface of the massager. Do not use a corrosive cleaner.

The fabric cover can be removed and cleaned separately by hand wash only.



INFORMATION ABOUT HAZARDOUS WASTE

Used products should be handled separately from household waste. They should be taken for recycling in accordance with local rules for waste management.

Troubleshooting

If you experience any problems during use, please refer to the following tips. If the product still doesn't work, please contact customer service.

PROBLEM	CAUSE	SOLUTION
Massager does not work.	No power.	Access the massager to a power supply..
A sudden stop.	Power is off.	Check that the power supply is connected..
	Massage time has exceeded 20 minutes.	Re-start by pressing the power button.
	Working time is too long, the massager is overheated.	Re-start after unplugging the massager and letting it rest for at least 20 minutes.
	Massage heads are blocked.	Make sure that your feet are relaxed during massage. Make sure that nothing else is trapped in the massager.

Technical data:

Product type: Foot massager
Product name: RELIEF Plus
Article no: MP-F58-N-1
Voltage: 12 V ⎓
Operating current: 3 A
Power: 36 W
Timer: 20 minutes
Weight: 3,7 kg.
Measures: 445 × 375× 420 mm.
Useage environment: 0 – 40 °C

Santé Sweden AB
VAT: SE556646715401
Phone: +46 20 27 27 20
www.massageprodukter.se

EU Declaration of Conformity

Compliant with European regulatory standards EMC 2014/30/EU and LVD 2014/35/EU.

Warranty Conditions:

The retailer guarantees a statutory period of warranty for the product described on the reverse. Warranty is valid from the date of purchase. The purchase date must be documented with proof of purchase. The retailer will repair or replace free-of-charge all items covered in each market for which faults have been discovered. A prerequisite is that you send the faulty device with proof of purchase before the guarantee or warranty period expires. The warranty claim shall not be applicable if a fault is established which has arisen e.g. due to external influences or as a consequence of a repair or modification which was not carried out by the manufacturer or an authorised dealer. The following points are not part of the warranty:

- Wear parts, e.g. abrasives, working synthetical parts, fabric covers, overlay / cover
- Wear caused by improper use
- Commercial use e.g. exhibition use, repeated use without intermediate breaks of 40 minutes
- Exposing the device to heat, humidity of liquids
- Damage due to sharp and/or sharp-edged objects
- Wanton destruction, misappropriation, overloading or accidental damage
- Damage and soiling by domestic animals
- Contamination caused by body or hair care products
- Damage caused by use of acids, solvent or alcohol agents

The warranty granted by the retailer is limited to repair and exchange of the product. Under this warranty, the manufacturer or the retailer shall have no further liability and are not responsible for damages which have arisen due to disregard of the operating instructions and /or improper use of the product. Where upon examination of the product by the manufacturer it is found that the warranty request does not concern a defect covered by the warranty or that the warranty period has expired, the customer must bear the costs for the inspection and repair.As manufacturer, Casada ensures the delivery of faultless goods to buyers/partners. Proven production faults are entitled to an exchange after registration and confirmation.

Legal note: All contents do not contain healing statements. The diagnosis and treatment of illnesses and other physical disorders require a treatment by a physician, non-medical practitioner or therapist. The statements are strictly informative and may not be used as a substitute for a professional medi-cal treatment. Every user is beholden to ascertain by accurate examination and, if required, after consultation of a specialist, if the application is the right one for their specific cases. Each dose or application takes place at the risk of the user. We dissociate ourselves from any healing statements or promises.

Copyright pictures and text are subject to the copyright of Santé Sweden AB. and may not be used without explicit confirmation. Copyright © 2026 Santé Sweden AB. All rights reserved.